Sangean

Sangean H02

蓝牙操作说明书

Wireless operation manual

蓝牙使用说明书

物品清单

1.耳机主体　　3.说明书

2.USB 充电线　　4.3.5mm双头连接线

1. ＋ 短按：音量+　长按：下一曲
2. 长按电源键开机/关机
   音乐模式：播放/暂停
   通话模式：单击：接听/挂断
   长按：拒听电话
   双击回拨最近一次电话号码
3. － 短按：音量-　长按：上一曲
4. 充电TYPE-C
5. Aux Input

规格参数

蓝牙版本: V5.3

有效距离: ≤10m

✻ 耳机工作时间:　约8个小时

电池容量:　300mAh

耳机充电时间:　约2.0小时

充电输入电压:　3.7V----5VDC

蓝牙功率:　2.402-2.480GHz

✻ 注意: 由于配对设备使用环境的不同, 耳机的工作时间有所不同。

蓝牙配对方法

长按电源键开机进入蓝牙配对模式,在手机上搜索"Sangean H02"点击进行配对。

耳机充电

开始使用时必须先充满电。USB充电线一头连接充电器或者电脑USB接口，一头连接耳机的 USB 充电口。红灯亮: 正在充电; 红灯灭: 充满电。

注意事项

请保持耳机干燥，不要放置在潮湿区域。

请勿长时间曝晒在阳光下以及放置在温度过高或者过低的环境中。

非专业人士请勿擅自拆开本产品。

请勿猛烈摇晃本产品以及用锐利物划伤本产品。

请勿使用化学物质清洁本产品。

请勿长时间连续充电本产品缩短电池寿命

请勿将耳机存放于温度高于50°C(122°F)或温度极低的环境中。

本产品只能在5°C-35°C(41°F-95°F)温度范围内使用。

请将耳机存放在孩童接触不到的地方。

耳机的较小部件可能会导致孩童窒息或受伤。

保修卡

本公司产品,保修期为一年,在使用过程中若发现问题

请及时与当地客服联系，以便及时售后处理。

以下情况恕不免费保修:

1.无保修卡三包凭证及有效发票的

2.超过三包有效期

3.因使用,维护,保养不当造成损失的

4.非本公司授权修理者拆动过的

5.保修卡上的内容与商品的实物标示不符的

6.因不可抗力造成故障或损坏的

注:根据本保修卡说明,凡属于正常使用情况下,由于产品本身质量问题引起的故障并在保修期内,本公司将负责给予免费保修。

制造商:深圳市音智航科技有限公司
地址:广东省深圳市龙华区光辉科技园厂房2栋2层203

保修卡

客户姓名: _____

联系电话: _____

地　　址: _____

产品型号: _____

购买日期: _____年_____月_____日

发票号码: _____

检修记录: _____

保修卡/合格证

请您妥善保管好保修证和购机凭证,这些将是您的保修凭证。

产品保修单(非人为损坏保修一年)

用户姓名		联系电话	
产品编号		购机日期	
通讯地址			
故障描述			

检修记录

序号	日期	检修记录	修理人员
1			
2			
3			

合格证

生产日期 _____

检验员 _____

Sangean

Sangean H02

蓝牙操作说明书

Wireless operation manual

User Guide

Check the Items

1.Headphone　　3.User Guide

2.USB charge cable　　4.Dual 3.5mm audio jack cable

1. ＋ Long press to next song
   Short press to increase the volume
2. Press and hold the power button
   to power on/off
   Music mode: Short press to play to
   pause the song!
   When a call comes in: short press to
   answer/hang up the call;
   Press and hold to reject the call.
   Press twice to redial the latest broadcast
   number.
3. － long press to last song,Short press the
   volume down.
4. Type-C Charging port
5. Aux Input

Product Specification

Bluetooth Version : V5.3

Effective distance : ≤10m

✻ Working hours of the headset :　About 8 hours

Battery capacity:　300mAh

Charge time of the headset :　About 2.0hours

Charging input voltage:　3.7V----5V DC

Bluetooth frequency:　2.402-2.480GHZ

✻ Note : Due to different pairing devices and using environment,the working hours of the headset are different

Bluetooth Pairing Operation Method

Long press to start the machine and enter bluetooth pairingmodel.At this time search the corresponding bluetooth device name"Sangean H02"on the phone, click the device name Sangean H02 on the mobile phone for the bluetooth pairing.

Charge the Headset

The internal rechargeable batteryinside must be fully charged before you start to use the headset .Connect one end ofthe USB cable to the charger orthe USB interface ofthe computer,and the other end to the charge interface of the headset. Red light on :charging .Red light off: charged fully .

Dos and Don ' ts

Keep the product dry . Do not store it in damp areas

Do not exposure the product to the sun or high temperature

Do not attempt to open the product , especially operated by non - professional person

Do not make the product fall down , shake the product violently , or strike the product with hard objects

Do not use harsh chemicals or cleaner to clean the headset

Do not use something sharp to scratch the surface of the product

Do not continuously charge the headset for over 10 hours to avoid affecting the service life

Do not store the headphones in temperatures above 50°C (122°F)or in extremely low temperatures

This product should only be used in temperatures ranging from 5°C-35°C (41°F-95°F).

Keep the headphones out of the reach of children. Smaller parts of the headphones may cause the childChildren are choked or injured.

Warranty card

The warranty period of our products is one year. If you find anyproblem during use.please contact the local customer service in timefor timely after-sales treatment.The following conditions are not free of warranty:

1.There is no warranty card certificate and valid invoice

2.The expiration date of three packages is exceeded

3.Losses caused byimproper use, maintenance or maintenance

4. It has not been removed by the repairman authorized by theCompany

5. The content on the warranty card is inconsistent with the physicallabel of thecommodity

6. Failure or damage caused by force majeure

Note: According to the description of this warranty card, the companywill be responsible for providing free warranty for any faults causedby quality problems ofthe products under normal use and within thewarranty period.

Manufacturer: Shenzhen Yinzhihang Technology Co., Ltd
Address: Room 203,Floor 2, Building 2,GuanghuiScience Park, Longhua District, Shenzhen,Guangdong, china

Warranty card

Customer Name: _____

Contact Number: _____

Address: _____

Product model: _____

Date of Purchase: _____Year_____Month_____Day

invoice No.: _____

Maintenance record: _____

Warranty card/certificate of conformity

Please keep the warranty certificate and purchase voucher properly,these will be your warranty certificates.Product warranty (one year warranty for non-human damage)

User name		Contact number	
Product number		Date of purchase	
Mailing address			
Fault description			

Maintenance records

serial number	date	Maintenance records	Repair staff
1			
2			
3			

Certificate

date of production _____

Inspector _____

495*80mm